UltraSmartCharger

Quick Start/Reference Guide

Quick Start:

Step 1: Insert SD card for logging (optional)

Step 2: Connect Power via USB Port

Step 3: Select the mode

Step 4: Select the charging rate

Step 5: Insert one or two NiMH/NiCd/NiZn AA-size batteries

Step 6: Push button for 1/4 second, 1 second

or 3 seconds to start

Mode switch positions:


Charge	Charge only
Drain	Discharge only, or cycles as
	per button press
Analyze	Runs charge/discharge
	cycles as per button press

Pressing the button:

- In Charge mode:
 - 1/4 sec.: Normal Charge
 - 1 sec.: Attempt to revive a dead battery, then normal charge
- In Drain mode:
 - 1/4 sec.: Discharge Only
 - 1 sec.: Discharge, then Charge
 - 3 sec.: Discharge, Charge, Discharge, Charge
- In Analyze mode:
 - ¼ sec: Charge, Discharge, Charge
 - 1 sec.: Charge, then Discharge, Charge, twice
 - 3 sec.: Charge, then Discharge, Charge, three times

Image below is Board Ver. 7

Primary Operational Locations:



- A Mini USB port (Power only no data access)
- B Mode Switch
- C Charging Rate Switch (High, Medium, Low)
- D SD Card Slot (Underneath, Optional)
- E Sub-mode Select Button
- F FTDI header (Data out and programming, Ground pin on right in above view)